

Sony Reader Digital Book

<http://tinyurl.com/yrrs4a>

The Sony Reader Digital Book is a reading device similar to the Kindle. You purchase books, magazines or blogs via Sony's online Connect eBooks Store then sync the books to the Reader via USB cable (the Reader does not include Wi-Fi capability). The USB cable also charges the Reader (or you can buy an optional AC charger). You can also read DRM-free e-texts (like those from Project Gutenberg) via the included secure digital (SD) or memory stick (MMS) slots. The eBook software is compatible with Windows. The Reader can handle e-texts in the following formats: PDF, RTF, DOC. It can also play audio files (MP3 & AAC formats), and display JPEG, GIF & PNG image files. The Reader costs about \$300.

1. To turn ON or OFF, slide switch to on the top of the device.
2. Pressing the **Menu** button when you first power on the Reader will bring up the master menu.
3. To navigate:
 - a. Use the **Menu button** on the lower right to return to the previous screen or show a menu.
 - b. Use **the wheel with left/right/up/down buttons** just below the Menu button to select items or scroll around the ascreen.
 - c. Use **the button in the center of the wheel** on the lower right to decide an item or apply a setting (think of it like the Enter key).
 - d. **Use the numbered buttons to the right side of the screen** to select numbered items on the screen or input numbers on the Settings menu.
4. While reading a book or magazine:
 - a. Use the **Page button on the lower left of the screen** to turn pages or proceed to the next chapter/section of content.
 - b. **Use the Size button** (it looks like a magnifying glass with a cross in it) on the lower left to zoom in or out of a page.
 - c. Use the **Mark button** (it looks like a tiny book with a turned page corner) on the lower left to bookmark content.
5. To return to the main menu at any time, press the **Menu** button on the lower left of the Reader.