

Amazon Kindle

The Kindle is a reading device. You purchase books, magazines or blogs via an Amazon account at the Kindle store. You connect to the store via Wi Fi. A USB charger is required to charge unit. It's available for \$399.

1. To turn ON or OFF, slide switch to on back of device.
2. To navigate
 - a. Use scroll wheel
 - b. Push scroll wheel to choose
3. Each screen has options which you get to by scrolling to **menu** at the bottom of the scroll bar and clicking the scroll wheel.
4. While reading a book or magazine
 - a. Use next page and prev page to move forward and back while reading.
 - b. To find a definition of a word in the text, highlight the line of text with your word in it, click the scroll wheel and choose **Lookup**
 - c. To search for a word in the text, press the **Search** button.
 - d. To bookmark a page in the book, scroll to the bottom where it says **Menu**, and click the scroll wheel, Select **Bookmark**
 - e. To add a note
 - i. Move your cursor to the line where you'd like to add your note.
 - ii. Press the scroll button, choose **Add note** and type away using the keyboard on the bottom.
 - iii. When finished, select done and click the scroll wheel.
5. To return to the main menu press the **Back** button on the right hand side of device.