

TECH CITY CANTINA



California Library Association 2008

Amazon Kindle

<http://tinyurl.com/6o2n2k>

The Kindle is a reading device. You purchase books, magazines or blogs via an Amazon account at the Kindle store. You connect to the store via Wi-Fi. A USB charger is required to charge unit. It's available for \$399.

1. To turn ON or OFF, slide switch to on back of device.
2. To navigate:
 - a. Use scroll wheel
 - b. Push scroll wheel to choose
3. Each screen has options which you get to by scrolling to menu at the bottom of the scroll bar and clicking the scroll wheel.
4. While reading a book or magazine:
 - a. Use **next page** and **prev page** to move forward and back while reading.
 - b. To find a definition of a word in the text, highlight the line of text with your word in it, click the scroll wheel and choose **Lookup**
 - c. To search for a word in the text, press the **Search** button.
 - d. To bookmark a page in the book, scroll to the bottom where it says **Menu**, and click the scroll wheel, Select **Bookmark**.
 - e. To add a note:
 - i. Move your cursor to the line where you'd like to add your note.
 - ii. Press the scroll button, choose **Add note** and type away using the keyboard on the bottom.
 - iii. When finished, select done and click the scroll wheel.
5. To return to the main menu press the **Back** button on the right-hand side of device.