

TECH CITY CANTINA



California Library Association 2008

Archos 605

http://www.archos.com/products/gen_5/archos_605wifi/index.html

The Archos 605 is a Wi-Fi enabled portable media player. You can download digital media to the device, watch TV, movies, view photos or browse the Internet. You can also view PDF files. It does not require batteries and is charged with a USB charger. It's available for around \$330.

1. To turn ON or OFF hold down the Power button on the top left side.
2. Touch the screen to choose what to do. Generally, you can double-click or click once and press the green OK button on the upper right side.
3. To go back a screen, either tap the **X** on the screen or push the **X** button on the top right key.
4. If a game is inserted, you will see the name of the game on the top of the touch screen. Tap it once to start the game.
5. To Play Big Brain Academy
 - a. Insert game card and follow onscreen instructions.
 - b. Click **Demo**.
 - c. Keep clicking the ▼ to get through the text on the top screen.
 - d. Choose a category and press **Start** onscreen.
 - e. To go back a screen click the arrow in the upper left.
 - f. To quit in the middle of a game, press the **Start** button (above **Select**).
6. To Play Guitar Hero
 - a. Attach the Guitar Accessory.
 - b. Insert game card and follow onscreen instructions.
 - c. Keep tapping the bottom screen until you get to a place where you can
 - d. Choose **Single Player**, then **Quickplay**.
 - e. To pause in the middle of a song, press the **Start** button (above **Select**).